

KEYLESS ENTRY REMOTE

ATTENTION: Refer to the appropriate shop manual for your vehicle to obtain specific service procedures for this part. If you do not have a service manual or lack the skill to install this part, it is recommended that you seek the services of a qualified technician. Pay special attention to all cautions and warnings included in the shop manual. Read and follow all instructions carefully.

Utilice este procedimiento para los vehículos con botones de información al conductor

Este procedimiento borrará todos los transmisores previamente aprendidos. Por lo tanto, los transmisores adicionales deben ser programados nuevamente en (paso 5)

Esta información está en el Manual del propietario en la sección central de información del conductor

1. Inserte la llave y active a la posición (ON) para que pueda acceder la información de controles del conductor
2. Pulsar el botón de información de vehículos hasta "RELEARN REMOTE KEY"
3. Pulsar el botón "set/reset" hasta "REMOTE KEY LEARNING ACTIVE"
4. Presione y mantenga el botón (unlock) abierto y cerrado (lock) en el llavero al mismo tiempo durante 15 segundos aproximadamente. Una campanilla sonará indicando que está programado el llavero.
5. Para programar otros mandos a distancia en este momento repita el paso 3. Este vehículo puede tener un máximo de ocho mandos a distancia programada.
6. Para salir del modo de programación desactive la llave y remueva la llave. Probar el llavero(s)

Utilice este procedimiento para los vehículos sin botones de información al conductor

Para acceder a esta pantalla, el vehículo estará parkado (P) con la llave en la posición (ON) (sin arrancar el motor)

1. Pulsar el botón del odómetro hasta mostrar "RELEARN REMOTE KEY".
2. Presione y mantenga el botón del odómetro durante 3 segundos. Hasta el mensaje "REMOTE KEY LEARNING ACTIVE".
3. Mantenga pulsado el bloqueo (lock) y desbloqueo (unlock) en el llavero al mismo tiempo durante 15 segundos aproximadamente. Una campanilla sonará indicando que está programado el llavero.
4. Para programar otros mandos a distancia en este momento repita el paso 3. Este vehículo puede tener un máximo de ocho mandos a distancia programada.
5. Para salir del modo de programación desactive la llave y remueva la llave. Probar el llavero(s)

Disclaimer:

Even though every attempt is made to ensure this information is complete and accurate, it is impossible to account for all possible circumstances or situations. Please consult with a qualified auto technician before attempting to perform any work you are not qualified to do. Automobiles can be hazardous to work on; be sure to take all necessary safety precautions. Failure to do so may result in property damage or personal injury. Certain motor vehicle standards and performance requirements may apply to your motor vehicle (such as Federal Motor Vehicle Safety Standards by the National Highway Traffic Safety Administration). Be sure that your work is performed in accordance with such standards and that you do not disable any motor vehicle safety feature.

©2012 Dorman Products, Inc.

No reproductions in whole or in part without prior written approval.